



Cascade-500 Series Gateway User Manual



Contents

Introduction	2
1 Planning	3
1.1 Coverage	3
1.2 Connections	3
1.3 Placement	3
2 Gateway Hardware	4
2.1 Specifications	4
2.2 Electrical Specifications	5
2.3 Interfaces	6
3 Mechanical Information	9
3.1 Cascade 500 Dimensions	9
3.2 Cascade 500-W dimensions	9
4 Installation	10
4.1 Equipment	10
4.2 Mounting Tools	10
4.3 Mounting Instructions	11
4.4 Hole Drilling Template	13
5 Gateway Setup	14
5.1 Initial Boot	14
5.2 Edge Direct Connection	15
5.3 Troubleshooting	15
6 Regulatory Information	16
6.1 Authorized Countries and Territories	16
6.2 FCC Statement	16
6.3 IC Statement	16
6.4 CE Statement	17
6.5 RF Exposure Statement	17
6.6 Non-modification Warning Statement	17

Introduction

Cascade-500 series Gateways are part of Rigado’s Cascade Edge-as-a-Service solution that offer powerful and cost-effective edge network infrastructure for large-scale, low-power wireless deployments. Cascade gateways provide commercial and enterprise IoT project and product teams with flexible edge computing power, a robust containerized application environment, and a variety of wireless device connectivity options.

Models included in this document	
Cascade 500	Edge Gateway with Bluetooth, WiFi, and Ethernet connectivity
Cascade 500-W	Edge Gateway with Bluetooth, WiFi, Ethernet and LTE Cat1/3G/2G cellular connectivity

Revision History

Version	Description	Date
V1.0	Initial Release	2018-8-21
V1.1	Add regulatory statements; sections 6.4 and 6.5	2019-9-11
V1.2	Added interface drawing and descriptions for Cascade 500-W	2019-9-13
V1.3	Clarify cellular info in section 2.1	2019-9-18
V1.4	Updated regulatory information in sections 2 and 6	2020-6-17
V1.5	Updated regulatory statement; section 6.4	2020-9-22

1 Planning

Planning is key to the success of any hardware installation. There are many things to consider when installing a wireless system into a space. Key elements for consideration are listed in the sections below.

1.1 Coverage

In a typical commercial space expected coverage area of about 4,000 sq. ft. per Gateway. However, the area of coverage for each Gateway is dependent on the layout and construction of the facility where it is installed. A Gateway in an open floor plan will have a larger coverage area than a closed floor plan with many walls. Building construction materials also affect coverage – drywall and glass permit more coverage than brick and concrete. Note that brick or concrete walls should be planned around, as signals have poor penetration through these types of walls. If coverage is required on both sides of a brick or concrete wall, plan for a Gateway on each side.

If a higher level of coverage planning precision is required, Rigado suggests using a Wi-Fi site planning tool to simulate coverage. There are multiple planning tools available online, both free and professional. For use in this application it should allow for changing the Access Points transmit power and characteristics for the Rigado Gateway.

1.2 Connections

The types of connections required should be taken into consideration when planning a new install. In order to function, the Gateway needs both a power and internet connection. For power, the options are Power over Ethernet (PoE) or AC wall power (adapters available upon request). For internet connection, the two options are Wi-Fi, Ethernet, or LTE (500-W only).

Rigado suggests using PoE-enabled Ethernet for Gateway connection. PoE connections allow for both data and power to be provided to the Gateway, requiring only one cable for installation. Special consideration needs to be given when choosing to use Wi-Fi, as the Gateway is an always-connected device without a physical user interface.

1.3 Placement

Correct placement of Gateways is important for getting the desired coverage. Generally, mounting Gateways up high and out of reach is recommended, as this improves line of sight while making the units more difficult to tamper with. Special consideration should be given to any metal near the mounting area, such as in support beams or HVAC ducts, as it is not recommended to mount the Gateway directly to any large metal surface.

Gateways do not need to be visible for operation. It is common to mount Gateways above drop ceilings, to either the wall or a drop from the ceiling. When mounting above drop ceilings or in open office style spaces, it is recommended to mount the Gateway below the level of any ceiling HVAC ducts to avoid dead spots.

2 Gateway Hardware

2.1 Specifications

Processor		
i.MX6ULL (Y2)	800MHz, 32bit ARM® Cortex™-A7	
Memory		
Memory (Volatile)	512 MB DDR3L SDRAM @ 400MHz, x16	
Memory (Bulk Storage)	8GB eMMC	
Wi-Fi (802.11a/b/g/n/ac)		
Frequency	2.412GHz - 2.472GHz; 5.180GHz – 5.700 GHz (region dependent)	
Modulations	DSSS, FHSS OFDM	
Transmit Power	19dBm for 2.4GHz band, 18dBm for 5GHz band, depending on modulation	
Receiver Sensitivity	-98 to -72dBm for 2.4GHz band, -92 to -68dBm for 5GHz band, depending on modulation	
Antenna	Integrated Dual-band Antenna	
Bluetooth		
BMD-345 Module		
Bluetooth Version	5 (Bluetooth Low Energy)	
LE Connections	Up to 6 connections supported	
Frequency	2.402 to 2.480 GHz	
Modulations	GFSK at 1Mbps, 2Mbps data rates	
Transmit Power	12dBm	
Receiver Sensitivity	-108 to -98dBm, depending on modulation	
Cellular LTE Cat1 with 3G/2G fallback (Cascade 500-W only)		
LTE Frequencies	700, 800, 850, 900, 1700/2100 (AWS), 1800, 1900, 2100, 2600 MHz (bands 1, 2, 3, 4, 5, 7, 8, 12, 18, 19,20, 28) (region dependent)	
UMTS/HSPA+ Frequencies	800, 850, 900, 1700/2100 (AWS), 1800, 1900 and 2100 MHz (bands I, II, IV, V, VIII, IX, XIX) (region dependent)	
GSM/GPRS/EDGE Frequencies	GSM 850, 900, 1800, 1900 MHz	
Modulations	GMSK/QPSK/16QAM	
Power Class (per listed 3GPP release)	EGSM850/900: Class 4, GSM1800/1900: Class 1, according to release 99 GSM 850/900/1800/1900 8-PSK: Class E2, according to release 99 UMTS 800/850/900/AWS/1800/1900/2100: Class 3, according to release 99 LTE 700/800/850/900/AWS/1800/1900/2100/2600: Class 3 according to release 8	
Antenna	Dual external dipole antennas, 5.0dBi	
GPRS/EGPRS Multislot Class	12	
Ethernet		
10/100 Base-T RJ-45 connector with PoE Support		
USB		
USB 2.0, A-type Host connector		
Dimensions		
Cascade 500 Enclosure	Length	127 mm
	Width	127 mm
	Height	30 mm
Cascade 500-W Cell antennas	Length	196mm
	Width	38mm
	Height	13mm

Hardware		
Power supply	4.5 to 5.5VDC, 2A max via Barrel Jack (5.5mm x 2.1mm)	36-57V (IEEE 802.3af) via Ethernet connector (RJ-45)
Temperature Range	0 to +60°C	
Certifications		
Cascade 500	FCC / ISED / CE-RED / RCM / UL / MIC	
Cascade 500-W	FCC / ISED / CE-RED / RCM / GCF / PTCRB / AT&T	

2.2 Electrical Specifications

2.2.1 Operating Conditions

Symbol	Parameter	Min.	Typ.	Max.	Unit
V _{AUX}	Operating supply voltage at barrel jack	4.5	5.0	5.5	V
V _{POE}	Operating supply voltage at Ethernet connector (PoE)	36	48	57	V
T _A	Operating ambient temperature	0	25	60	°C

2.2.2 USB Connector Power

Symbol	Parameter	Min.	Typ.	Max.	Unit
V _{USB}	Operating output voltage at USB connector for loads up to 500mA ¹	4.5	5.0	5.5	V

2.2.3 Power Consumption

Symbol	Parameter	Min.	Typ.	Max.	Unit
P _{5V}	Power consumption ² referenced at 5V input (5V_IN)		1	10	W

2.2.4 Absolute Maximum Ratings³

Symbol	Parameter	Min.	Max.	Unit
V _{AUX_MAX}	Voltage at barrel jack ⁴	-5	12	V
V _{POE_MAX}	Voltage at Ethernet connector (for PoE)	-0.3	60	V
T _S	Storage temperature	-20	70	°C

1. USB is an output only – the unit will not run from power supplied to the USB port
2. Power consumption is very dependent upon the unit configuration (SKU) and the application. MAX power for units without a USB load is about 3W (600mA@5V in).
3. Do NOT operate the unit under these conditions.
4. The unit will NOT operate over this voltage range. Prolonged exposure to these conditions is also NOT recommended.

2.3 Interfaces

Interface features are described throughout this section, including power and data connectivity, and button and LED location and behavior.




Figure 1 – Cascade Gateway – Back View

2.3.1 Ethernet with Power over Ethernet support

The Gateway is equipped with a single 10/100 Base-T Ethernet connector. For configurations supporting PoE (802.3af), the Gateway will operate when powered by either a PoE switch (end-span) or injector (mid-span).

2.3.2 Reset Button

The reset button provides both soft and hard reset capabilities, depending on the length of the press. The timing is described in the following table:

Reset Action	Time	Behavior
Quick Press	< 2 seconds	Soft Reboot
Short Press	2-4 seconds	Network Reset
Long Press	10-15 seconds	Hard Reset
Very Long Press	> 30 seconds	Factory Reset

2.3.3 USB

A USB 2.0 Type-A connector on the Gateway board provides access to a High Speed (up to 480Mbps) USB host.

2.3.4 Barrel Jack

The Gateway provides a 5.5mm x 2.1mm barrel jack for 5V DC input. Any AC/DC wall adapter used to power the gateway needs to be rated up to 2A. Please note that actual current consumption is dependent upon programmed snaps deployed on the Gateway.




Figure 2 - Cascade Gateway - Top and Bottom View

2.3.5 Front Button

A front facing button is located on the face of the Gateway. This button is not enabled on the default Gateway configuration.

2.3.6 Multi-color LED

A multi-color (red/green/blue) LED located near the user button provides a means of visual indication for the user. For additional information regarding LED behavior, please refer to docs.rigado.com.

2.3.7 Cable Cover

The back of the unit has a snap-in cover for improved cable management. This allows for hidden cable routing when the unit is installed on a wall or ceiling. The cable cover is removable.




Figure 3 – Cascade 500-W Gateway – Back View

2.3.8 SIM Card Slot


Cascade 500-W units also have a small slot on the back of the enclosure near the USB connector and reset button. This is a push-push type slot that fits a micro SIM (3FF).

2.3.9 Antenna Connector


Two SMA type connectors are visible on one side of the unit where the provided cellular antennas attach. Only the antennas provided with the Cascade 500-W unit are certified for use on cellular networks.

3 Mechanical Information

3.1 Cascade 500 Dimensions



3.2 Cascade 500-W dimensions




4 Installation


4.1 Equipment

Each Cascade Gateway comes with following equipment in the box:


- 1 x Cascade Gateway
- 2 x Cellular Antennas (500-W only)
- 1 x Power supply with international adapters (optional)
- 1 x Wall/Ceiling Mount Kit:
 - 1 x Cascade mounting bracket
 - 1 x Cascade ceiling backer plate
 - 4 x M3 x 50 mm Length, Pan Head, Phillips #1, Machine Screw
 - 4 x Screw, Pan Head Phillips Sheet Metal #6/18x1.25"
 - 4 x Drywall Anchor, #6-#8 Screw, 1-1/4" Length



Cascade Gateway



Mounting Bracket




Ceiling Backer Plate



Ceiling Mount Screws
M3 x 50 mm Phillips (x4)



Wall Mount Screws
#6 x 1-1/4" Phillips (x4)



Drywall Anchors (x4)

4.2 Mounting Tools


To use the Wall/Ceiling Mount kit provided, the following tools are required (*not included*):

- Phillips screwdriver
- Drill and drill bit - 3/16" for wall, or 1/8" (3-4 mm) for ceiling mounting
- Drywall saw or keyhole saw for 1" cable pass-through hole

4.3 Mounting Instructions


Rigado recommends mounting the Gateway with the tab pointing to the side (mounting bracket installed as shown below). This correctly orients the antennas and maximizes Gateway coverage.

1. Use the mounting bracket as a template to mark the hole locations on the wall or ceiling. If mounting to the wall, use a 3/16" (5 mm) drill bit. If mounting to a ceiling tile, use a 1/8" (3-4 mm) drill bit. If a hole is needed for any cables, also mark this in the appropriate cable opening space in the mounting bracket.




2. Attach the mounting bracket to the surface using the appropriate method:

Wall Mounting




Push the provided drywall anchors into the drilled holes, then place the mounting bracket snugly against the wall. Using a screwdriver, screw the wall mount screws into the drywall anchors.

Ceiling Mounting




Place one ceiling mount screw through one of the mounting bracket screw holes, and push through the corresponding drilled ceiling hole. Use this screw to guide placement of the ceiling backer plate to the opposite side, then use the screwdriver to screw in this and the remaining ceiling mount screws.

3. Once the mounting bracket is installed, line up the four hooks of the mounting bracket with the corresponding holes on the back of the Gateway and press the two together. To lock in place, slide the Gateway over towards the cabling hole until it clicks into place.




4.4 Hole Drilling Template

This template is at scale and can be printed for use.



5 Gateway Setup

Before the Gateway is permanently installed, look at the bottom (mount side) and record the unit Serial Number (1) or scan the 2D barcode (2), as shown below.



5.1 Initial Boot

At first power on, the Gateway’s LED indicator will display the boot status. The status of the Gateway can be determined using the following table:

LED color	LED activity	Status
Yellow/Amber	Solid	Appliance is booting
Yellow/Amber	Slow-blink (1 blink every 2 seconds)	Appliance is in provisioning sequence
Yellow/Amber	Fast-blink (2 blinks per second)	Provisioning is complete, appliance is authenticating
Green	Solid	Appliance is provisioned and authenticated with Rigado Edge Direct

5.2 Edge Direct Connection

Once the Gateway is successfully booted, it should show up on your [Edge Direct](#) homepage. To find the Gateway, navigate to 'Gateways' and look for the matching serial number. Select that unit and a live status page will appear, showing current status and utilization. This is your primary user interface for configuring the Gateway's applications and updates. For further details on Gateway configuration reference our Edge Direct documentation at docs.rigado.com.

5.3 Troubleshooting

Should you experience issues with any of the above steps, or with the Cascade-500 / Cascade-500-W Gateway in general, please visit our technical documentation portal at docs.rigado.com. If you have an issue that is not resolved in our documentation, or if you have a more application-specific question, please reach out to us at support@rigado.com.

6 Regulatory Information

6.1 Authorized Countries and Territories

The Cascade-500 and Cascade-500-W are authorized for use in the following countries:

Afghanistan, Anguilla, Australia, Austria, Bangladesh, Belgium, Bulgaria, Canada, Comoros, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Georgia, Germany, Greece, Guadeloupe, Hong Kong, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Martinique, Myanmar, Netherlands, New Zealand, Norway, Poland, Portugal, Romania, Saint Barthelemy, Saint Martin, Slovakia, Slovenia, Spain, Sweden, Switzerland, Turks and Caicos, United Kingdom, USA.

The Cascade-500 is also certified for use in Japan.

6.2 FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

6.3 IC Statement

This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, these radio transmitters may only operate using provided antennas approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec des antenne fournies approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

6.4 CE Statement

Rigado, Inc. declares that The Cascade-500 and Cascade-500-W comply with the essential requirements and other relevant provisions of Radio Equipment Directive 2014/53/EU. A copy of the Declaration of Conformity is available on request.

Rigado, Inc.

101 SW Main St., Suite 2000

Portland, OR 97204 USA

6.5 RF Exposure Statement

This equipment complies with the radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 35cm between the radiator and any part of the human body.

6.6 Non-modification Warning Statement

Changes or modifications to this equipment that are not expressly approved by Rigado could void the user's authority to operate the equipment.